

Peel & Seal DRIVEWAY PATCH

From the makers of
American Road Patch™

Project Materials List

- » Broom
- » Shovel
- » Tamper
- » Utility knife or scissors
- » Cold or hot asphalt fill mix

INSTRUCTIONS



1. Remove broken, crumbled asphalt material from the pothole.
2. Clean surrounding surface; remove all dust, debris, etc.
3. Be sure repair area is clean and dry before applying patch.
4. Fill and seal intersection cracks around repair area.
5. Fill the pothole with a cold or hot asphalt fill mix.
6. Compact this material so that the surface of the fill is level to the surface of the driveway.
7. Cut the patch to extend beyond the existing pothole by 4" on all sides.
8. Peel the release film off the back of the patch.
9. *Apply patch to repair. Roll, tamp, or compress the sheet down to the clean, dry surface.
10. Drive over patch upon completion as additional compaction will aid in Peel & Seal Patch embedding into the surface.

**If the ambient temperature during application is below 75°F apply propane torch to surface (asphalt or concrete), where the patch will be placed and heat the surface to a minimum of 200°F.*



Scan
ME!
For additional information
including video
instructions, & FAQ's visit
www.adfors.com/driveway



**SAINT-GOBAIN ADFORS
America, Inc.**

140 John James Audubon Parkway,
Suite 102
Amherst, NY 14228
Phone: 800-762-6694

www.adfors.com