

FibaTape®

SELF-ADHESIVE REPAIR PATCH



TIME REQUIRED: 15 minutes + dry time



SKILL LEVEL: Easy

TOOLS & MATERIALS

- Wall repair kit

Includes everything you need to complete the project

- (1) 4 in. Self-adhesive repair patch
- (1) 4½ in. Sandpaper
- (1) 3 in. Spreader
- (1) 8 fl. oz. Tub of spackle



PATCH SIZE:

4"x4" - covers holes up to 3" (7,6 cm)

INSTRUCTIONS:

1. Select patch size 1/2" larger than the hole on all sides.
2. Clean repair surface area removing any loose debris. Wipe away dust.
3. Peel away patch liner and apply patch to surface. Center patch over the hole. Press down firmly on all edges.
4. Using taping knife, apply compound. Feather around edges, concealing the patch. Allow to dry.
5. Sand repair site lightly, then apply a thin finishing coat of compound. Allow to dry.
6. Sand to a smooth finish. Additional finish coats may be applied as needed.
7. Prime and paint.

