

FibaTape®

SELF-ADHESIVE REPAIR PATCH



TIME REQUIRED: 15 minutes + dry time



SKILL LEVEL: Easy

TOOLS & MATERIALS

- Electrical outlet repair patch
- Taping knife
- Joint compound
- Sanding block

PATCH SIZES:

7"x7" - covers holes up to 5" (12,7 cm)

INSTRUCTIONS:

1. Clean area to be repaired, removing any loose debris.
2. Peel away liner and apply patch over outlet and entire area, pressing firmly around all edges.
3. Using utility knife, cut along inside edges of outlet box and remove excess mesh.
4. Using taping knife, apply compound. Feather around edges, concealing the patch. Allow to dry.
5. Sand repair site lightly, then apply a thin finishing coat of compound. Allow to dry.
6. Sand to a smooth finish. Additional finish coats may be applied as needed.
7. Prime and paint.

